

INSTALLING THE DOOR AND JAMBS



PHASE 1

Fix the brackets to your door, 120mm from each edge of the door.



PHASE 2

Insert the locking nut in its seat and connect the bolt washer on the runners.



PHASE 3

Insert the runners into the track ready to hang the door.



PHASE 4

Insert the plastic pins on the door guide in these positions.



PHASE 5

Using the two self tapping screws, fix the guide to the frame. Remember the door must be routed to accept the spigot.



PHASE 6

Mount the door into position ready for fixing.



PHASE 7

Fix the door into position temporarily.



PHASE 8

Make sure the door is ABSOLUTELY true and vertical.



PHASE 9

Now fix the door into position permanently.



PHASE 10

Measure and cut the doorpost and jambs.



PHASE 11

Fit the rubber gaskets to the doorpost.



PHASE 12

Fit the brushes to the jambs.



PHASE 13

If fitting the door guide, trim the bottom of the jamb to fit.



PHASE 14

Screw the mounting bracket to the back of the door post.



PHASE 15

Position the doorpost and screw the bracket to the frame.



PHASE 16

Fix the position of the door stop in the track.



PHASE 17

Use spots of silicon to attach the jambs to the frame.



PHASE 18

Attach the vertical jambs.



PHASE 19

Measure the horizontal jambs.



PHASE 20

Cut to the required length from one jamb length.



PHASE 21

Fix the two horizontal jambs to the vertical jambs.



PHASE 22

Cut your architraves (not supplied)



PHASE 23

Position and fix the architraves (not supplied)



PHASE 24

The final result is extremely practical and looks good!



COUNTERFRAMES FOR POCKET DOOR SYSTEMS

Em-B Solutions Ltd

42-44 Burley Road, Leeds West Yorkshire, LS3 1JX

Tel : 0113 245 9559

Fax : 0113 245 9779

Email : info@em-b.co.uk

www.em-b.co.uk